














Összeszerelési útmutató

A		1 KS
B		1 KS
C		2 KS
D		4 KS
E		1 KS
F		2 KS
G		32 KS
H		16 KS
I		32 KS
J		2 KS
K	 K1 K2 M5 x 70mm M4 x 65mm	1 KS
L	 CSK M4 x 25mm	2 KS
M	 CSK M4 x 50mm	8 KS

