










KDZ x11D


PL Instrukcja montażu
EN Assembly instructions
DE Montageanleitung
LV Instalēšanas instrukcijas
RU Инструкция по установке
UK Інструкція по установці
RO Instrucțiunile de instalare
HR Upute za montažu

FR Instructions d'installation
NO Installasjonsinstruksjoner
LT Instaliavimo instrukcijas
FI Asennusohjeet
SK Pokyny na inštaláciu
HU Telepítési utasítások
CS Pokyny k instalaci
SV Monteringsanvisning

1.




| | | | |
|--|---|--|--|
| <p>A1</p>  <p>8</p> | <p>B1</p>  <p>4x25</p> <p>12</p> | <p>C1</p>  <p>2</p> | <p>D1</p>  <p>2</p> |
| <p>E1</p>  <p>4x10</p> <p>8</p> | <p>F1</p>  <p>1</p> | <p>G1</p>  <p>4x12</p> <p>2</p> | <p>H1</p>  <p>1</p> |






/2

2.




/3

3.




/4

4.



5.



6.

